



Dismantling Instructions The Milo Storage Bed

Help Line 01327 226275

DISMANTLING THE MILO STORAGE BED

Clear the space around the bed. Remove the mattress and empty the contents of the drawers.

To remove the four large drawers: Open the drawer to its full extension. A black plastic lever will be visible on each drawer runner. By simultaneously holding the lever on the left hand side of the drawer down, and the lever on the right hand side runner in the up position, the drawer can be slid off the runner.

Undo the 12 woodscrews (1) fixing the slats to the frame and remove the slats (2).

At the foot end, undo and remove the nut and threaded rod (6) attaching the centre rail and the end carcass.

Remove the two end carcass cover panels: From inside the end carcass un-do the two fixing screws (5) for each panel. Slide out the cover panels.

Remove the slat centre support rail by gently tapping it from underneath at each end with a mallet, to split the connectors at each end.

At the foot end of the bed unscrew the two bracket screws (7) at each side and remove the foot end rail.

From behind the headboard, remove the two woodscrews (3) which connect the headboard to the side surround rails, with the allen key provided Loosen the two headboard fixing screws (4) each side and remove the headboard.

Removing the side carcass: From underneath the bed remove the woodscrews (9) that connect the side carcass to the side rails. Each side of the carcass is connected to the head and foot end carcasses by two connecting fittings (8). Undo these (You may require help to hold the head of the screws in the side drawer units to prevent them turning). The side carcass can now be slid out towards the centre of the bed and lifted clear.

Remove each side rail in turn by unscrewing the three screws into the foot end carcass and the two screws into the head end carcass (11) using the allen key provided.

